

Fitting Instructions #2251KIS

Ford Falcon BA Sedan 10'02

Rear Shock Absorber Upper Mount (OE Only)



Note: Polyurethane bushings must be fitted to both sides of the vehicle.

- Jack the vehicle up and support on jack stands/hoist;
- Using factory manual, remove the rear shock absorber from the rear suspension;
- Remove original bush from the housing with the use of a hydraulic press or suitable pressing tools;
- Apply the grease supplied to the bore of the bush, and the outside of the crush tube;
- Push the new polyurethane bushing into the housing as shown in the illustration, then the crush tube;
- Refit the shock absorber to the vehicle and tighten all bolts to manufacture's torque settings.

