

Fitting Instructions #5424IS

Nissan Pathfinder R50

Steering Rack & Pinion Mount Bushing



- Jack/hoist the vehicle up and support on jack stands, remove the underbody covers.
- Remove the two bolts on each rack clamp and remove the clamps.
- Remove the old rubber bushes from the rack.
- Install SPF2681 on the drivers (Right) side of the vehicle and SPF4660 on the passenger (Left) side of the steering rack.
- Reinstall the rack clamps and tighten down to manufacturer specifications.
- A wheel alignment is recommended after installation of steering rack bushings.