

Fitting Instructions #1144IS

Subaru Leone

Trailing Arm Bushing Kit



This kit requires the use of the original equipment steel shell. Therefore the steel outer shell must be left in the arm and only the original equipment rubber bush is to be removed.

Note: There is **no** bond between the rubber and the shell. The rubber bush can therefore be removed, by lowering the front of the trailing arm and using a suitable puller to remove the rubber bushes.

- Using grease supplied: Grease the inside of the shell in the trailing arm and the outside of the polyurethane bush supplied, then push the bushings into arm;
- Then grease the inside of the polyurethane bushings and the outside of the crush tubes supplied and press the tube into place. The arm can then be bolted back into position.

Note: the use of the original centre crush tube is not required.