

Fitting Instructions #1487IS

Toyota Landcruiser Prado

Rear Sway Bar Bushing

- Jack the vehicle up and support on jack stands;
- Remove the sway bar bush brackets;

Note: in some cases, the sway bar needs to be disconnected to allow clearance to install the new bushes.

- Remove original bush part from the sway bar with suitable tools;
- Clean the brackets and sway bar to remove any old original bushing materials before installing new bushes;
- Apply the grease supplied to the bore and outside of the bush and install it as show in the picture*;
- Refit the brackets (and sway bar) to manufacturer's settings.

