

Fitting Instructions #0281IS

Ford Zephyr / Zodiac / Consul

Control Arm Lower Inner Bushing



This kit requires the fitment of support washers to be installed as per the drawing below.

- Remove the old original bushing from the housing. Use a wire brush and or emery paper to clean the inside of the housing.
- Using grease supplied, Grease inside of housing, grease outside of bushing and install new bushing into the housing.
- Grease new steel tube and install in bushing.
- Install the new steel washer supplied on to the mounting pin.
- Assemble the arm on to the mounting pin.

Note: re-use the original washer under the retaining nut.

The drawing shows the correct assembly (It is strongly recommend that new split pins be used on assembly).

