

# Fitting Instructions #2769IS

## Toyota Supra JZA80

### Rear Differential – Pinion Bracket Mount Supplement Washers



- Jack up and support rear of vehicle to suitable working height;
- Support rear differential with suitable props/jacks that will allow it to be lowered;
- Undo main differential to vehicle attachment points and lower differential so that original thrust washers may be removed from vehicle;
- Install #2547W Steel Washers and #2769 Polyurethane Bushings marked "UPPER" to the tops of the differential pinion bracket mounts and raise differential back into it's installed position;
- Assemble #2742A Polyurethane Bushings and OE Stopper 41654-30010 and retain with original bolts;
- Replace and re-tighten all fasteners to manufactures specifications.

