

NISSAN GQ AND GU PATROL

***SPECIAL KIT FITTED WITH OFFSET CRUSH-TUBES FOR EXTRA CASTER!**
Fitment for drivers side and passenger side trailing arms to increase caster. Bush and Tube fitment is identical for both arms.

Lay the trailing arm on this template and mark the bush positions as indicated.

Press in the bush with the hole closest to the mark. Distance between hole centers must be 240 ± 1 mm for easy fitting.

*SPF1721XK : - Offset 10mm
(SPF1721K: - Offset 6mm)

FRONT

240

