

Fitting Instructions #TRC1001

Holden Commodore

VE Front caster arm replacement kit



NOTE: This kit must be fitted to both sides of the vehicle

- Wheel-align the vehicle before the job is started and note settings;
- Jack the vehicle up and support on jack stands/hoist;
- Using factory manual, remove front caster arms from the front suspension;
- Replace the old front caster arm with TRC1001LH/RH arms from Superpro kit to the vehicle and tighten all bolts to manufacture's torque settings with arm in RIDE HEIGHT POSITION;
- Refit wheels and carry out wheel alignment;
- If additional caster is required install SPF2859K (included in TRC1001 kit)



Control arm must be tightened when arm is at ride height