

Fitting Instructions #3097IS

Subaru Impreza, WRX GH

Rear Trailing Arm Front Bushing

Note: Polyurethane bushings must be fitted to both sides of the vehicle.

- Support the vehicle on jack stands or a hoist and remove the trailing arm;
- Use a hydraulic press to remove the O.E. bush;
- With the use of an arbor press or similar, push in the new polyurethane bush marked '3097', use a metal disc or similar on top of the part to make installation easier, also a small amount of grease around the edge of the arm will help;
- Use the white grease supplied to lubricate the bore of the bush, outer diameter of the crush tube and the faces of the bush, push in crush tube;
- Fit the large diameter washer over the mounting peg, then put the arm on the peg and fit the small diameter washer over the bolt. Re-assemble arm and carry out a wheel alignment.

