

# Install Guide

## Rear Toe Control Arm Outer Joint Nissan Patrol Y62



**Note:** These components must be fitted by a qualified person only, as per the manufacturer's service manual. Also, all relevant safety procedures are followed in addition to the following. Photos are an indication and may vary slightly in appearance from the actual product.

### Kit Contents:

- 2x Spherical Bearing

1. Place an adjustable stand or jack under the rear lower toe arm. Remove the M14 bolt from the outer end of the toe arm.
2. Slowly lower the arm to relieve spring pressure until the spring becomes loose.
3. Once the outer bushing is separated from the arm, it can be removed.
4. Using a press tool kit and threaded rod, press the OEM bushing out through the rear of the knuckle.
5. Install the new Spherical Joint by reversing the removal process. Use the same threaded rod to pull the new bearing into place until it sits flush with the knuckle.



6. Reinstall the toe arm by raising it back into position and refitting the OEM bolt.
7. Repeat the process on the opposite side.
8. Torque all bolts to the manufacturer's specifications.
9. Perform a wheel alignment.
10. Recheck all bolts after 1,000 km or 1 month, whichever comes first.