

# Fitting Instructions #0879IS

Nissan Navara, Urvan, Pathfinder, Terrano, 720

## Control Arm Upper Inner Kit



- This kit requires the use of the original equipment steel shell. Do not remove this shell. Original equipment rubber must be removed by the following procedure:

**Note:** this procedure must be carried out in a well-ventilated area.

- Use an oxy-acetylene torch to warm the inner tube, to destroy the rubber bond and remove the tube.
- Next, heat the outer shell to destroy the bond between the outer shell and the rubber bush. Remove the rubber bush.
- Further heating can be used to clean any remaining rubber from inside the shell. Use a wire brush and emery paper to clean the shell.
- Using the grease supplied, grease:
  - Inside the shell;
  - Outside and inside of the bush;
  - Outside of the tube.
- Press the bush into the shell, then insert the tube into the bush.

