

Fitting Instructions #0458IS

Chevrolet Corvette C4

Front Control Arm Lower-Inner Bushing

Note: Polyurethane bushings must be fitted to both sides of the vehicle.

- Wheel-align the vehicle before the job is started and note settings;
- Jack the vehicle up and support on jack stands/hoist;
- Using factory manual, remove the front lower control arm of the front suspension;
- Remove original bushings from the housing;
- Apply the grease supplied to all mating surfaces;
- Push the new polyurethane bushing into the housing as shown in the illustration, then the crush tube;
- Apply the grease supplied to the bore of the bush and the outside of the crush tube and use an arbour press to install the crush tubes;
- Refit the front lower control arms to the car and tighten all fasteners to manufacturer's torque specification.
- Carry out wheel alignment.

