

Fitting Instructions #3228IS

Ford Falcon FG

Front sway bar to chassis bush

- Remove the front sway bar brackets and lower the sway bar;
- 2) Remove the brackets and sway bar bushes. Discard the O.E. metal bracket that is sandwiched between the flat surface of the sway bar bush and the subframe – refer to picture;
- 3) Apply grease to the bore of the new bush marked '3228' and the sway bar;
- 4) Refit sway bar to the car and tighten the nuts.

