

Fitting Instructions #5274IS

Ford Territory

Front Radius Arm to Chassis Mount Bushing

Note: Polyurethane bushes must be fitted to both sides of the vehicle.

- Wheel align the vehicle before the job is started and note castor settings.
- Remove the Front Radius Arms from the vehicle.
- Remove original bushings from the Radius Arms with the use of a hydraulic press and suitable pressing tools.
- Press the new bushing into the Radius Arms, insuring that equal amounts of the new steel outer shell protrude out each side of the bracket approx. 10mm each side as per photo below.

