

Fitting Instructions #1740IS

Mitsubishi Pajero, Triton, Strada Control Arm Upper-Inner Kit



Photo 1: Remove the upper control arm from the vehicle and remove both outer lock nuts.



Photo 2: Heat the control arm with an oxy torch to delaminate the bush from the outer shell (Do not allow the rubber to catch fire) Place the control arm in a vice and force the arm off the bush.

Remove the bush and repeat the procedure for the other end. Do not remove the outer shell of the OE bushing, as this will be used to locate the new bushing.



Photo 3: Clean the inner surfaces of the OE shells. Lube all mating surfaces with the grease provided and assemble one bush into the arm and insert the inner tube.

Photo 4: Assemble the other bush into the arm and then insert the inner tube.

Photo 5: Refit and tighten both lock nuts and repeat the procedure for the remaining control arm. Refit both control arms to the vehicle and Wheel align the vehicle.

