

Fitting Instructions #5319IS

Isuzu D-Max / Mazda BT-50 2020-On

Brake Line Spacer

- Jack the vehicle up and support on jack stands/hoist.
- Remove the original brake line retaining clip.
- Pull the steel sleeve down until there is enough room to install the '5319' brake line spacer over the brake hose in the orientation shown below.
- Push the brake line spacer in the hole and install the original brake line retaining clip onto the groove in the spacer.
- Use a zip tie to further secure the brake line spacer around the steel sleeve as shown in the image below.

