

# Fitting Instructions #TRC1005IS

## Subaru Impreza WRX

### Support Brace

- With the vehicle on jack stands/hoist, remove the lower control arm inner and sway bar bracket bolts of the rear suspension;
- Install the TRC1005 brackets as it is shown in the picture below;

Lower control arm bolts and nuts. The 1.6mm thick washers should be placed on the braces (between the brace and the bolt head), as indicated in the pictures.

Sway bar bracket bolt



Sway bar bracket bolt



**Note** that the supplied 5mm washer should be placed between the brace and the sub-frame, as indicated in the pictures.

Tighten all mounting bolts to manufacture's specifications.