

- Remove the control arms from the vehicle;
- Grease the faces of the polyurethane spacer washers, and push them onto the tubes. The spacers are to be arranged as depicted in the diagram below;
- Note some models with the protruding mounting peg will require the use of supplied washer. Position this washer onto mounting peg before offering up control arms as per diagram below.
- Refit the control arms and washers into the vehicle ensuring triangular mounting plate is reinstalled.
- Wheel align vehicle and check new settings;
- All mounting bolts are to be tightened to manufactures specifications with the vehicle at ride height.

