

Fitting Instructions #1312IS

Volvo 240, 260

Rear Trailing Arm Rear Bushing



This kit requires the use of the original equipment steel shell. Original rubber bush must be removed by the following procedure, which has to be carried out in a well-ventilated area:

1. Using an oxy-acetylene torch, warm the inner tube to destroy the rubber bond. Then remove the tube;
2. Repeat the previous procedure, heating the outer metal shell, to destroy the bond between the outer shell and the rubber bush;
3. Remove rubber bush. Further heating can be used to assist in removing any remaining rubber from the shell. Use a wire brush and emery paper to complete the cleaning of the shell;
4. Using grease supplied, grease the inside of the shell, grease bushes and install as indicated in the above diagram;

Note: chamfered bush 1312 must be installed from the "Road Wheel" side of the shell.

5. Grease inside of the installed bushes, grease tube supplied and install the bushing.

