

Fitting Instructions #4297IS

Subaru WRX, Impreza, Liberty, Forester

Rear Differential Centre Support Void Filler

- Set the car up on a hoist and remove the OE nut of the differential rear bush, and keep the OE bolt in place;
- Install the inserts, washers and reinstall the original nut as shown in the picture;
- Tighten all the bolts and nuts to the manufacture's recommended torque settings.

