

Fitting Instructions #TRCDDHILIS

Toyota Hilux 2005 –

Prado 120 series 2002 – 2010

Prado 150 series 2010 –

FJ Cruiser 2006 – 2016

Diff Drop Kit



- 2 x M12 x 1.75 x 160
- 2 x 49mm x 25mm (13mm ID) alloy round spacers
- 4 x M12 flat washer
- 2 x M12 nyloc nuts
- 4 x M8 x P1.25 x 45L
- 4 x M8 split washer
- 4 x 24.5mm x 25mm (8.6mm ID) alloy round spacers

- 1) Raise vehicle on hoist or jack and use suitable axle stands to support vehicle
- 2) Remove 4 bolts from sump guard
- 3) Remove 2 bolts from front diff mounts
- 4) Using 2 x large black spacers, place between chassis and front diff mounts
- 5) Secure front diff mount using 2 x M12 bolts, 2 x M12 nuts and 4 x M12 washers provided, tighten up to factory specification (117 Nm)
- 6) Using 4 x small spacers, fit sump guard to vehicle placing spacers between sump guard and chassis. Secure with 4 x M8 bolts and 4 x M8 split washers provided. Do not use original bolts. **Mounting holes in sump guard may need to be elongated to allow sump guard to fit correctly**

**** SuperPro recommends all work is carried out by qualified mechanic****