

Fitting Instructions #2305IS

Ford Focus

Rear Sway Bar Link Pin Bushing



- Remove the front factory sway bar links from the lower control arms and sway bar;
- Remove the factory bushes from the bolt;
- Using original bolt with the SPF2305K SuperPro kit, install the new sway bar link with reference to the diagram;
- Note orientation and location of the '2305' bushes and washers;
- Tighten the bolts and ensure that they are torque to manufacturer's specification.

Original Configuration



SuperPro Configuration

