



**Fitting of this bar should be carried out by qualified persons only.**

1. Jack the Vehicle and place on support stands.
2. Fit the Chassis plates, link pins, bolts and nuts as per the photo. (Use existing Bumper Bar mounting bolt/Tighten to Manufacturer spec) **Do not tighten links yet**

Note position of the LH bracket in the photo and match the RH side.



Note: Supplied is 2 different length links. The short ones are for STD height vehicles whilst the longer are for raised Vehicles to give more off-road articulation

3. Fit the Sway Bar To the links on both sides,
4. Swing the bar up towards the Diff (hold the bar up with a stand of some sort).

5. Fit one side U/bolt, Diff plate D/bracket and D/bush to the bar and nip up the nuts

6. Repeat on the other side



Note: the D/bush butts against the lock ring and in turn the U/bolt sits against the Brake hose brackets

7. Tighten the U/bolts and Links



Recheck positioning making sure the bar is central and clear of all obstacles. Torque all bolts before lowering the vehicle off the stands

**Please drive carefully to get used to the new handling characteristics.**