

Fitting Instructions #3616IS

Volkswagen Polo MKV 6R

Rear Axle Front Bush

- Note bushes can be installed without removing axle beam;
- Jack the vehicle and place on floor stands or raise on a two-post hoist. Remove the road wheel;
- Support axle beam centrally with jack stand. Remove the axle front bush pivot bolts only – leave shock absorber bolts in place;
- Use the jack stand as support and lower the axle enough to gain access to bushes (approximately 100mm). Be careful not to stretch brake lines.
- Use suitable press tools tap OE plastic shell bush out of housing;
- Clean the inner surface of the arm. Apply the grease provided to all mating surfaces of the arm, new bush and steel tube;
- Push in the new bushes according to the schematic. Insert the steel tube provided;
- Assemble in the reverse order of removal. Refit all mounting bolts using manufactures torque settings.

