

Fitting Instructions #0601IS

Holden Commodore

Rear Bump Stop Kit



The original foam insert **Bump Stop** must ***not be fitted*** to the new design **SUPER LOW Bump Stop**. To obtain the optimum Ride, Comfort and Load Carrying capacity the foam must be left out.

Fitting Instructions #0601IS

Holden Commodore

Rear Bump Stop Kit



The original foam insert **Bump Stop** must ***not be fitted*** to the new design **SUPER LOW Bump Stop**. To obtain the optimum Ride, Comfort and Load Carrying capacity the foam must be left out.

Fitting Instructions #0601IS

Holden Commodore

Rear Bump Stop Kit



The original foam insert **Bump Stop** must ***not be fitted*** to the new design **SUPER LOW Bump Stop**. To obtain the optimum Ride, Comfort and Load Carrying capacity the foam must be left out.

Fitting Instructions #0601IS

Holden Commodore

Rear Bump Stop Kit



The original foam insert **Bump Stop** must ***not be fitted*** to the new design **SUPER LOW Bump Stop**. To obtain the optimum Ride, Comfort and Load Carrying capacity the foam must be left out.