

Fitting Instructions #3359IS

Mitsubishi Lancer / Outlander

Rear Control Arm Upper Inner Bushing

- Jack the vehicle up and support on jack stands;
- Remove the control arms;
- Remove original shell/bush part from the housing with the use of a hydraulic press and suitable pressing tools;
- Clean housing areas to remove any old original bushing materials before installing new bushes;
- Push the new bushes in the arm as shown in the picture;

Note: there is not a specific side to press the bushes.

- Apply the grease supplied to the bore of the bush and the outside of the crush tube, then push in the crush tube as shown in the picture.
- Refit the control arms to the vehicle and tighten all bolts to manufactures torque settings.



Note: Polyurethane bushings must be fitted to both sides of the vehicle. Re tension all bolts at 1000 km