

# Fitting Instructions #0010IS

Mazda RX7

Watts Link Bushing Kit



**Important:** during assembly, position crush tube with stepped shoulder and supplied washer facing towards the vehicle rear

