

# Fitting Instructions # RC0003RZIS

## Suzuki Swift

### Sway Bar Stabiliser Kit

---

**Note:** Photos are for instruction purposes only and not necessarily exact to part number.

**Fitting of this bar should be carried out by qualified persons only.**

- Jack the Vehicle and place on support stands;
- Place a Jack underneath the rear beam and remove the bottom shock mounting bolts;
- Lower down the Jack and remove the springs.(Be careful not to stretch the brake hoses or damage the ABS cables;
- Remove all parts from packaging;
- Loosely assemble the plates onto the Sway bar using Cap screws supplied. The notch on the plates goes towards the front of the vehicle;
- Fit the bar and plates to the underneath of the rear spring mounts using 2 of the smaller bolts per side in the existing holes of the spring mount;
- Tighten all of the bolts;
- With an 8mm drill bit drill the other holes in the spring mount using the sway bar mount plate as the template;
- Fit and tighten the other 2 bolts per side.



Please drive carefully to get used to the new handling characteristics.