

# Fitting Instructions #4559IS

## Nissan Elgrand E50

### Rear Panhard Rod Bushings

**Note:** Polyurethane bushings must be fitted to both sides of the vehicle.

- Wheel-align the vehicle before the job is started and note settings;
- Jack the vehicle up and support on jack stands/hoist;
- Using factory manual, remove the panhard rod/suspension link;
- Remove original bushings including the steel shell from the housing with the use of a hydraulic press and suitable pressing tools;
- Apply the grease supplied to all mating surfaces;
- Push the new polyurethane bushing into the housing as shown in the diagram, and then the crush tube;
- Refit the panhard rod/suspension link to the vehicle and tighten all bolts to manufacture's torque settings.
- Carry out wheel alignment.

