

Fitting Instructions #5502IS

Hyundai i30 N

Rear Blade Arm Front Bush Kit



Note: Polyurethane bushings must be fitted to both sides of the vehicle.

- With the vehicle on jack stands/hoist, remove the rear blade arms;
- With the use of a hydraulic press and suitable pressing tool, remove the factory bushes including the steel shell;
- Clean housing areas to remove any old original bushing materials;
- Using the appropriate pressing tools support the control arm and press in the new shell of the bushing first, ensure the **correct offset in the arm as per OEM**;
- Apply a light smear of grease to the part 5502 and press into the shell;
- Press the laser cut plate into the 5502A as per diagram below, the narrow end of the plate will enter at the end with the part number on 5502A;
- Grease the inside of 5502 and outside of 5502A and press 5502A into 5502 to achieve the correct orientation of the **oval hole as OEM**;
- Refit the rear blade arms to the vehicle and tighten the bolts;
- Ensure that all fasteners are torque to manufacturer's specification and carry out a wheel alignment.

