

Fitting Instructions #4824IS

Toyota Fortuner

Rear Panhard Rod Bushing

Superpro
Suspension Parts

End attached to
the differential

End attached to
the Chassis

- Jack the vehicle up and support on jack stands/hoist;
- Remove the rear panhard rod;
- With the use of a hydraulic press and suitable pressing tools, remove original bushes;
- Using the grease supplied, lubricate the housing and the outside surface of the new '4824' and '4828' bushes and push them in as shown in the figures;
- Generously lubricate the outside of the steel tube and inside of the bush, then push the steel crush tube into the bush;
- Refit the panhard rod to the vehicle and tighten all bolts to manufacture's torque settings.

Note: Polyurethane bushings must be fitted to both sides of the vehicle.

