

# Fitting Instructions #4795IS

## Mercedes S-Class

### Front Sway Bar to Chassis Bushing

---

*Note:* This kit must be fitted to both sides of the vehicle.

- Wheel align the vehicle before the job is started and note wheel alignment settings;
- Remove the front factory sway bar brackets that are attached to the chassis;
- Remove the OE bushes and clean sway bar and the brackets;
- Install the new Swaybar bushes and the OE brackets;
- Tighten the bolts and ensure that they are torque to manufacturer's specification;
- Wheel align vehicle and check new settings.

