

Fitting Instructions #1061IS

Commer Van 1500 and 2500 / Humber Supersnipe Series I - VA

Control Arm Lower Inner Bushing



Front lower control arm inner pivot #1061K

Front control arms outer pivot #1226k

This kit replaces the steel internally threaded outer section of the mechanical pivots

The original pivot pins must be re-used.

1. With the relevant component removed from the vehicle, unscrew the pivot pins;
2. Using a hydraulic press (or similar) remove the internally threaded steel outer case from the control arm or stub axle, being careful to ensuring that the housing is not damaged;
3. Clean & grease housing surfaces;
4. Insert the Polyurethane bush ensuring that the internal thread is well greased;
5. Re-assemble by screwing the threaded pins back in the usual manner;
6. Components can then be replaced in the vehicle. These parts can be greased, as normal, with a grease gun.