

Fitting Instructions # RC0083RZ-22IS

Ford Falcon AU-FGX Ute

Sway bar Stabiliser Kit

This work should only be carried out by qualified person

1. Raise vehicle and support diff on jack stands. Sway bar to be fitted at ride height;
2. Fit the sway bar to differential using the U-Bolts, Bushings and Brackets supplied. Leave the nuts loose at this stage. U-Bolts should be fitted as far out as possible to keep sway bar centred as per image below.

Note: You may have to carefully pull the brake pipe back to clear the U/Bolts. Be careful of the ABS and hand brake cables.



Figure 01 – Sway bar installation – Rear View.

3. Fit link to sway bar and bracket, fasten m10 bolt and nut to bracket, then swing sway bar into place and use bracket as template to drill 10mm hole in chassis as shown in Figure 02 and 03;



Figure 02 – Sway bar link installation.



Figure 03 – Sway bar link installation.

4. Recheck position making sure the sway bar is central and clear of all obstacles. Torque all bolts before lowering the vehicle off stands.

Note: The link should be vertical at ride height.

All bolts should be torqued after 1000 kilometres.

Please drive carefully to get used to the new handling characteristics of your vehicle.