

## Fitting Instructions #1971IS

### Alfa Romeo Alfeta 75

#### Rear Watts linkage Centre Pivot

---



- One metal washer is included in this kit;
- This washers is required to captivate the polyurethane cotton-reel. It should be fitted on the pivot mounting pin in front of the polyurethane bush;
- All other washers are to be re-used in their original positions (The original "front" washer must be left in place, as it has an internal chamfer which matches the chamfer on the mounting pin).

## Fitting Instructions #01971IS

### Alfa Romeo Alfeta 75

#### Rear Watts linkage Centre Pivot

---



- One metal washer is included in this kit;
- This washers is required to captivate the polyurethane cotton-reel. It should be fitted on the pivot mounting pin in front of the polyurethane bush;
- All other washers are to be re-used in their original positions (The original "front" washer must be left in place, as it has an internal chamfer which matches the chamfer on the mounting pin).

## Fitting Instructions #1971IS

### Alfa Romeo Alfeta 75

#### Rear Watts linkage Centre Pivot

---



- One metal washer is included in this kit;
- This washers is required to captivate the polyurethane cotton-reel. It should be fitted on the pivot mounting pin in front of the polyurethane bush;
- All other washers are to be re-used in their original positions (The original "front" washer must be left in place, as it has an internal chamfer which matches the chamfer on the mounting pin).

## Fitting Instructions #1971IS

### Alfa Romeo Alfeta 75

#### Rear Watts linkage Centre Pivot

---



- One metal washer is included in this kit;
- This washers is required to captivate the polyurethane cotton-reel. It should be fitted on the pivot mounting pin in front of the polyurethane bush;
- All other washers are to be re-used in their original positions (The original "front" washer must be left in place, as it has an internal chamfer which matches the chamfer on the mounting pin).