

Fitting Instructions #3452IS

Nissan X-Trail T31 MkII 2WD and 4WD

Front Lower Control Arm Inner Rear Bushing (To suit Right-hand drive vehicles)

Note: Polyurethane bushings must be fitted to both sides of the vehicle.

- Wheel-align the vehicle before the job is started and note settings;
 - With the vehicle on jack stands/hoist remove the front wheels and remove the lower control arms, note undoing the lower swaybar link make the removal/install a lot easier;
 - Remove original shell part from the housing with the use of a hydraulic press and suitable pressing tools, take care to prevent stretching arm;
 - With reference to the diagrams and the settings required, align the bushing with the bracket so that the hole in the bush is positioned to give the desired result;
 - Press the bushes into the housings making sure to leave 5mm of the shell from the top of the control arm;
 - The crush tubes can now be fitted to the bushes. A generous amount of the white grease supplied must be applied to both the bore of the bush and the outside of the crush tube;
- Fit the spacers supplied over the crush tubes top and bottom, use the white grease supplied to lubricate the spacers;
 - Refit the control arms and swaybar links;
 - Wheel-align vehicle and check new settings;
 - All mounting bolts are to be torqued to manufactures specifications.





Figure1.


Fitting Instructions #3452IS

As viewed from the top of the control arm.

Kit #3452K – Standard Replacement. No castor change.



Kit #3453K – To counteract a slight pull to the left
Single Offset, Passenger side castor increase (+0.5 degree).



Kit #3454K – To Counteract a Strong pull left
Double Offset, passenger +0.5 degree and driver -0.5 degree castor.





Figure2.

Table 1: Illustration of Castor Settings