

Fitting Instructions #0610IS

Nissan Skyline / Pintara

Trailing Arm Lower Bushing All



The application of SPF610K is to be completed by a hydraulic press only.

- Use chassis stands to support vehicle underbody at a suitable height to allow axle to be at maximum suspension extension.
- Remove the rear lower control arms & acquire a support tool to fit the flange (lip) of the steel part in the arm.

Note: do not support the outer arm, support the flange (lip) of the shell housing & ensure that enough clearance is given for the inner steel shell to be pressed out.

- Using a press out tool remove the inner steel shell.

Note: only the inner steel shell is to be removed from the flange housing.

- After the removal of the inner steel shell using the grease provided lubricate the outside of the bush as well the inside.
- Fit the polyurethane bush to the housing & ensure that the large head size of the bush is the same side as the flange (lip) of the housing.
- Fit the steel tube & fit the rear lower control arms to the car.