

Fitting Instructions #RC0027RZIS

Holden Rodeo

Sway Bar Stabiliser Kit

This work should only be carried out by qualified persons.

- Raise vehicle and support Diff on Jack stands.Sway bar to be fitted at ride height;
- Fit the sway bar to the differential using the U/Bolts, Bushings and Brackets supplied. Leave the nuts loose at this stage;

Note: You may have to carefully pull the brake pipe back slightly to clear the U/Bolts. Be careful of the ABS cables.



- Fit the Chassis brackets and links as per the below picture using U/bolts, Bolts and washers supplied. The U bolt should be mounted over the Chassis rail in front of the cross brace.The U bolt should be biased towards the outside of the chassis for clearance purposes .Leave loose at this stage;
- Attach the Links to the Sway bar with bolts and washers supplied. Make sure the large washer is on the outside of the link supporting the bush;





- Centralise the Bar on the differential and tighten the U/Bolts. Do not over tighten as the brackets will bend and the u/bolt thread will strip;
- Make sure the links are on the same angle left and right. You may have to tweak the exhaust bracket so it clears the link;
- Tighten the links and Mounting brackets at ride height.



Please drive carefully to get used to the new handling characteristics.

Super Pro Roll Control does not take responsibility for incorrect fitment or misuse of this product.

Pictures are indicative and are not necessarily exact to the B.O.M