

Fitting Instructions #1265IS

Toyota Camry, Avalon / Lexus ES300

Control Arm Lower Rear Bushing



Special Note: polyurethane bushes must be fitted to both sides. Careful attention when pressing the bushes in.

Kit #1265K : Standard Alignment

Contains:

- 2 x 1265 Bushes & 2 x 1265 Tubes, original equipment style bushes which will maintain existing caster settings.

Kit #1266K : 0.5 Degree Caster Adjustment Left Side

Contains:

- 1 x 1265 Bush & 1 x 1265 Tube. To be fitted to the right hand side (Maintains existing caster setting).
- 1 x 1265 Bush & 1 x 1267 Tube. To be fitted to the left hand side (Off-set hole gives +0.5 degree caster).

Kit #1267K : 0.5 Degree Caster Adjustment Per Side

Contains:

- 2 x 1265 Bush & 2 x 1267 Tube (+0.5 degree caster left-side / -0.5 degree caster right-side).

Note: mounting brackets and pivot shafts must be free of dirt, rust & corrosion. Ensure that all bush surfaces in contact with metal are coated with the grease provided.

All mounting bolts are to be tightened to manufacturer's specifications with the vehicle at ride height.