


# Fitting Instructions #4354IS

Honda Odyssey RB


## Control Arm Lower Inner Front Bush (Front)

Left Hand Side Shown



**Note:** Polyurethane bushings must be fitted to both sides of the vehicle.


- Wheel-align the vehicle before the job is started and note settings;
- Jack the vehicle up and support on jack stands;
- Remove the lower control arms;
- Remove original shell part from the housing with the use of a hydraulic press and suitable pressing tools;
- With reference to the diagrams and the settings required, align the bushing with the bracket so that the hole in the bushing is positioned to give the desired result;
- Apply the white grease supplied to the bore of the bush, the outside of the crush tube and the inside of the polyurethane spacers;
- Push in the crush tube and fit the polyurethane spacers with reference to the diagram below;
- Refit the control arm to the vehicle. Tighten all bolts to manufactures torque settings;
- Carry out a wheel alignment.




**Note:** the orientation of the Spacer Washers.

**As viewed from the top of the control arm.**

**Kit #4354K** – Standard Replacement. No castor change.



**Kit #4355K** – To counteract a slight pull to the left  
Single Offset, Passenger side castor increase.



**Kit #4356K** – To counteract a strong pull left  
Passenger Side castor increase, Driver Side Castor decrease.

