

Fitting Instructions #4981IS

Mitsubishi Triton MK , Pajero NH-NL, Challenger PA

Front Upper Control arm Bushing Kit

- With the vehicle on jack stands/hoist, remove the front upper control arms;
- Mount arms in a vice remove retaining nuts and original shell part bushings from the housings with the use of an air chisel and suitable pressing tools;
- **Important retain all original washers and nuts noting orientation**
- Clean housing and cross shaft to remove any old original bushing materials.
- Insert cross shaft into arm followed by the inner washer grease bore of bush with lubricant supplied and press into arm housing so it sits up against arm
- Using an Arbour Press or similar press crush tubes into the bushes
- Refit the outer cupped washers with the cup section dished away from the bush then refit retaining nuts
- Fit arm to vehicle and torque retaining nuts to 115 Nm
- Carry out a wheel alignment.



Triton / Pajero Upper Control arm

