

Fitting Instructions #3757IS

Toyota Hilux

Shock Absorber Bushing

Note: Polyurethane bushes must be fitted to both sides of the vehicle.

- With the vehicle on jack stands/hoist, remove rear wheels and then remove the rear shock absorbers from the vehicle;
- Remove the OE bushing;
- Position the "3757" and "3758" bushes as shown in the figure;
- Refit the rear shock absorbers and rear wheels to the vehicle;
- Ensure all bolts are tightened to the manufacturer's specification and then proceed to have the vehicle wheel-aligned.

