

# Fitting Instructions #1590AIS

## Holden Commodore VE

### Strut Top Bushing

- Jack the vehicle up and support on jack stands;
- Remove the struts;
- Remove original top strut bush with the use of suitable tools;
- Install the new polyelast top strut bush with the supplied uprated heavy duty washers. Important to use the supplied **uprated heavy duty flat washer on top**, as specified by General Motors;

**Important Note:** the washer installed on the bottom of the bush should be orientated as it is shown in the picture below\*;

- Refit the strut to the vehicle and tighten all bolts to manufactures torque settings;
- Carry out a wheel alignment.

