

Fitting Instructions #4557IS

Holden Barina

Rear Beam Axle to Chassis Bushing

- With the vehicle on jack stands/hoist, undo the bolts and lower the beam axle;
- With suitable tool, press the factory shell bushes out. They are plastic shells and can be easily removed;
- Clean housing areas to remove any old original bushing materials;
- Apply the grease supplied to outside and inside surfaces of the bushes and the outside of the steel crush tubes;
- Install the new bushes according to the orientation shown in figure, placing the '4558' bush on the inner position and the '4557' bush on the outer position;
- Refit the beam axle to the original position and tighten all the bolts;
- Ensure that all fasteners are torque to manufacturer's specification and carry out a wheel alignment.

