

Fitting Instructions #2056IS

Mitsubishi Pajero NM - NX

Rear Lower Control Arm Bushes

Note: Polyurethane bushes must be fitted to both sides of the vehicle. This kit should be installed by a Qualified Motor Mechanic.

- Jack the vehicle up and support on hoist/stands then, remove the rear wheels;
- Crack the rear camber pin loose then, remove the outer bolt (Hub side) and lower shock absorber bolt. Ensure the lower control arm is supported and then, lower it to remove the coil springs. Proceed to remove the inner bolt, then remove the rear lower control arms from the vehicle;
- Thoroughly clean all contact areas with a wire brush.
- Remove the original bushes including the outer metal shell for the fitment of this new kit. **Please Note:**
 - #2056 is fitted to the outer position;
 - #2057 is fitted to the inner position.
- Ensure that the grease supplied is used on all mating steel surfaces during assembly.
- Refit the rear lower control arms and re-assemble the rear end of the vehicle in reverse order of disassembly.
- Manufacture's torque setting must be used on all bolts, wheel align the vehicle and check new settings.
- Recheck all bolts after 1000km or 1 month;

Right Hand Side Shown - As viewed from the rear of the vehicle



Bush marked '2057'
fits the inner position

Bush marked '2056'
fits the outer position