

# Fitting Instructions #2272IS

Chrysler PT Cruiser

*Sway Bar Link Bushing Kit*

---

- This kit includes 4 washers that are to be fitted as shown.

