Fitting Instructions #0206IS



Land Rover Range Rover, 90, 110, Defender, Discovery / Honda Crossroad Radius Arm to Chassis Mount Bushing

Removal and installation of the radius arms should be carried out in accordance with the manufacturer's instructions.

<u>Please note this kit has two types of bushes:</u>

- The parts marked "0206A" plain outside diameter bushes, should fitted onto the radius arm on the front side of the chassis mount (and will be contained by the original cupped washer).
- The parts marked "0206B" which have a groove around the body diameter, should be fitted onto the radius arm on the rear side of the chassis mount (and will be contained by the original flat washer);

Using the grease supplied, ensure that grease is applied to all surfaces of the bush which come in contact with the surrounding metalwork.