

Fitting Instructions #1140IS

Mitsubishi Lancer / Hyundai Lantra / Proton Saga Control Arm Lower Rear Bushing



Special Note: Polyurethane bushes must be fitted to both sides of vehicle.

Kit # 1140K - Standard Alignment

Contains:

- 2 x 1140 L & R Bushings, original equipment style bushes which will maintain existing caster settings.

Kit # 1141K - 0.6 Degree Caster Adjustment Left Side

Contains:

- 1 x 1140 R Bushing. To be fitted to the right hand side (Maintains existing caster setting).
- 1 x 1142 L Bush. To be fitted to the left hand side (Off-set hole gives +0.6 degree caster).

Kit # 1142K - 0.6 Degree Caster Adjustment Per Side

Contains:

- 2 x 1142 R&L Bushing (+0.6 degree caster left-side / -0.6 degree caster right-side).

Note: mounting brackets and pivot shafts must be free of dirt, rust & corrosion. Ensure that all bushing surfaces in contact with metal are coated with the grease provided.

Fitting the appropriate bushing to the car. The word "front" is moulded to the bushing. This is to face forwards & to the front of the car (the word "front" is visible once fitted).

All mounting bolts are to be tightened to manufactures specifications with the vehicle at ride height.