

# Fitting Instructions #2811IS

Mitsubishi Pajero NM, NP

Rear Upper Control Arm Inner Bushes

The original bush outer metal shell must be removed for the fitment of this kit.

Ensure that the grease supplied is used on all mating steel surfaces during assembly.

**Note:** The front and rear bushings in the control arm have different flange thicknesses, please be careful to make sure:

- #2811 marked 'FRONT' is fitted to the front eye, with the larger diameter, wide flange and metal washer positioned toward the front.
- #2812 marked 'REAR' is fitted to the rear eye, with the large diameter, narrow flange and metal washer positioned towards the rear.



Front Bush 2811



Rear Bush 2812