

Fitting Instructions #0788IS

Hyundai Sonata / Mitsubishi Magna

Control Arm Lower Rear Bushing



This Kit is designed for Right-hand drive Vehicles

Special Note: polyurethane bushes be fitted to both sides.

SPF577K - Standard Alignment Passenger's and Driver's side

Contains:

- 2 x SPF577 Bushes to be fitted to the passenger's and drivers side's (Maintains existing caster settings).

SPF652K – Passenger's side Increase Caster and Driver's side Standard Caster

Contains:

- 1 x SPF652 Bush to be fitted to the passenger's side (+0.8 degree caster (increase) passenger's side);
- 1 x SPF577 Bush to be fitted to the driver's side (Maintains existing caster driver's side).

SPF788K – Passenger's side Increase Caster and Driver's side Decrease Caster

Contains:

- 2 x SPF652 Bushes to be fitted to both the Passenger and Driver sides (+0.8 degree caster (increase) passenger's-side / -0.8 degree caster (decrease) driver's-side).

Note: mounting brackets and pivot shafts must be free of dirt, rust & corrosion. Ensure that all bush surfaces in contact with metal are coated with the grease provided.

- Fitting the appropriate bush to the car. The word "front" is moulded to the bush. This is to face downwards & to the front of the car (the word "front" is visible once fitted);
- All mounting bolts are to be torqued to manufacturers specifications with the vehicle at ride height.